

PANOPREY® - ACRYLIC PANEL

Touch Finish



Touch

These care instructions apply to vertical and horizontal decor installations.

These are general guidelines. Users are advised to follow the recommendations issued by the manufacturers of the cleaning products.

The Touch finish has innovative surface properties, allowing easy repair of superficial micro scratches.

Our products do not require any protective surface treatment on first use.

They are treated with an antibacterial treatment that inherently reinforces cleaning and disinfection procedures. This antibacterial treatment contributes to general hygiene management by reducing microbial contamination and so increasing surface hygiene.

1. RECOMMENDED CLEANING EQUIPMENT



Microfibre cloth
Soft cloth



Single-use wipe











Non-abrasive sponge










Magic eraser

2. CARE GUIDELINES

FREQUENCY	OPERATION	METHOD	EQUIPMENT	CARE PRODUCT	TECHNIQUE
First use (initial cleaning)	Dusting	Manual	   <p>preferably using hot water</p>	Diluted soapy water or a household detergent	<ul style="list-style-type: none"> • Clean from top to bottom, moving from clean areas to dirty areas • Begin by rubbing gently using a soft microfibre cloth • For residual stains, apply soapy water or detergent using a sponge or a single-use wipe. Spray the detergent onto the cloth rather than directly onto the surface • Rinse with hot water and wipe up any residual moisture using a microfibre cloth to prevent residual stains from forming • Follow the contact times and rinsing guidelines for the detergents - avoid products that are too concentrated and viscous
Daily care	Dusting			Same as first use	
	Descaling	Manual	  	Solution containing citric or acetic acid diluted to 10% or household white vinegar	<ul style="list-style-type: none"> • Manually clean any stains or deposits caused by water • Rinse with water and wipe using a soft microfibre cloth • In case of stubborn stains, use a damp magic eraser and then dry using a soft microfibre cloth
	Fingerprints	Manual	 	Hot water	<ul style="list-style-type: none"> • Clean with a soft, dry cloth or magic eraser • If residual marks remain, clean using a sponge and soapy water, rinse with water and wipe using a soft, clean cloth to prevent water stains from forming • Do not use detergents

3. GUIDELINES ON STAIN REMOVAL AND REPAIR

FREQUENCY	OPERATION	METHOD	EQUIPMENT	CARE PRODUCT	TECHNIQUE
End of building works & Daily use of product	Removing glue, paint and varnish stains	Manual	 	<ul style="list-style-type: none"> • Acetone • Methylated spirits • Green solvent • White spirit • Soapy water 	<p><u>Immediately wipe off as much product as possible before it hardens</u></p> <ul style="list-style-type: none"> • Clean with a soft cloth and a diluent • Clean with a sponge and soapy water to remove any excess cleaning product • Rinse with water and wipe dry using a soft cloth <p>Stubborn/old stains :</p> <ul style="list-style-type: none"> • Repeat previous steps until stain fades or disappears • A damp magic eraser may occasionally be used with soapy water provided the stain is no more than a few hours' old

FREQUENCY	OPERATION	METHOD	EQUIPMENT	CARE PRODUCT	TECHNIQUE
End of building works & Daily use of product	Removing silicone sealant	Manual		<ul style="list-style-type: none"> • White spirit • Methylated spirits • Green solvent 	<p>Immediately wipe off as much product as possible before it hardens</p> <ul style="list-style-type: none"> • Rub gently with a soft cloth and a cleaning product • Clean with a sponge and soapy water to remove any excess cleaning product • Rinse with water and wipe with a soft microfibre cloth to prevent water stains from forming
	Removing food stains (coffee, tea), organic matter (blood), grease, pen marks, etc.	Manual	  	<ul style="list-style-type: none"> • Soapy water • Methylated spirits • Green solvent 	<p>Recent/fresh stains :</p> <ul style="list-style-type: none"> • Begin by immediately wiping with a soft, dry cloth • For residual stains, clean manually using a soft cloth, preferably with soapy water • For stubborn stains, use a household detergent • Rinse with water • Always wipe with a soft, clean cloth to prevent water stains from forming <p>Stubborn/old stains :</p> <ul style="list-style-type: none"> • A damp magic eraser may occasionally be used with soapy water provided the stain is no more than a few hours' old • Always wipe with a soft, clean cloth to prevent water stains from forming
Repairs and touchups	Repairing superficial micro-scratches	Manual		Water	<ul style="list-style-type: none"> • Apply the magic eraser to where the superficial scratches are located. The sponge may be used wet or dry Rub gently until the micro-scratches disappear • Dry using a soft cloth <p>NB: The surface repair method should only be used occasionally so as not to alter the surface's appearance.</p>

Stain and chemical resistance

The surface of Touch acrylic has good stain resistance, but careful attention must be paid to its deep, matt microstructure if coffee or tea stains are left to sit for more than 2 hours on the material's surface. These may leave very faint stains, particularly on light, more sensitive decors. We recommend that you begin cleaning the stain as soon as the staining agent touches the surface. Please note that the finish has a tight, non-porous surface. Vulnerability to certain stains is not due to the absorption of liquids but to its deep matt microstructure.

DO NOT USE

- Abrasive sponges or products such as silica-based cleaners, scouring powder, steel wool, Moroccan black soap, etc.
- Buffing or waxing products, or any products which might leave a greasy film
- Strong acidic or alkaline cleaning products, drain cleaners, silverware or pipe cleaners (descaling products, hydrochloric acid, drain cleaners, silverware cleaners, etc.)

GENERAL RECOMMENDATIONS

- Avoid exposing surfaces to water or cleaning products for prolonged periods of time
- It is recommended that you always wipe the surface after cleaning using a soft microfibre cloth in order to prevent stains
- If possible, minimise the use of products which may cause smears while cleaning
- If stains appear as a result of limescale or water being left to sit, follow the cleaning guidelines on page 2
- Apply the cleaning agent to the cloth rather than directly onto the Touch surface